

Main Window (Hyperlink Table)

Sample Alignment

Test Intensity

Measurement of Rest Intensity

Definition of Accuracy


Sender Polarisation

Single Measurement

Multiple Measurements

Continuous Measurements

Time depending Measurement



List Window

Simulation Window

Supervisor Functions

Sample Alignment

Test Intensity

Measurement of Rest Intensity

Definition of Accuracy

Sender Polarisation

Single Measurement

Multiple Measurements

Continuous Measurements

Time Depending Measurement

List Window

Simulation Window

Supervisor Functions

<http://www.youtube.com/watch?v=Nlf-rGebTro>

<http://www.youtube.com/watch?v=ERgioAlsg9k>

<http://www.youtube.com/watch?v=5hBgKhGDcFM>

<http://www.youtube.com/watch?v=v0Asptmj8Po>

<http://www.youtube.com/watch?v=IFaMufjl1hw>

<http://www.youtube.com/watch?v=9jYv7aSu0yk>

http://www.youtube.com/watch?v=Cf_e9fh1nlw

<http://www.youtube.com/watch?v=B8ZkjRdo7K8>

→ Hyperlink Table 'List Window'

→ Hyperlink Table 'Simulation Window'

→ Factory Use